MS-CAPCUT INSTRUCTION MANUAL





Mesrutiyet caddesi. Hatay Sokak. 17/B 06640. Kızılay / Ankara Turkey

Tel: +90 312 417 72 75 Fax: +90 312 425 72 81 Web: www.oliser.com.tr Email: oliser@oliser.com.tr

Instructions:



First open the door and choose appropriate cartridge cradle. Place it in the cave which is infront of the blade. You can use the cradles for below mentioned cartridges;

- HP 27/28/56/57/58/59
- Lexmark 16-17


Place the cartridge inside the cradle,


make sure it fits properly.

- Lexmark 12A1970



Before





After