

# CENTRIFUGE



Place the cartridges as shown to get empty through fill hole plugs.

Here only 78 series cartridges are shown, you can place different foam type cartridges such as HP 25/49 , 27/28/56/57/58 series, LEX 1970/1980/13400 , 10N series



Secure the cartridges with plate as shown left.



On/Off power switch placed on the right side of centrifuge, when the top cover is open, motor will stop automatically and start centrifuge when top cover closed.



While using the centrifuge put a waste container.

## WARNING

Input power supply cord should be connected to a ground fault circuit interrupt type outlet.